

CONTROL DEVICE CRANECAMERASYSTEM VH-4015

VH-5409



VH-5540



Viewing angle adjust:

Press "Rear" to change the viewing angle to the front

Press "Front" to change the viewing angle to the back

Zoom function:

Press "Zoom wide" to zoom out

Press "Zoom tele" to zoom in

Switching the camera on:

Press and hold "Zoom tele" to switch the camera and monitor on

Switching the camera off:

Press and hold "Zoom wide" for 10 seconds to switch the camera and monitor off

Changing the video channel:

Press "Zoom tele" for 15 seconds to change the video channel